

1. PAPPER UPPER ATTACHMENT **PLACEMENT**

CONTENT



Open and check the content of the boxes and take out all the pieces carefully.

PAPER ATTACHMENT **BY CLICK FRAME**



FLIPCHART REVERSIBLE 700x1000MM 13.949-2 *ASSEMBLY INSTRUCTIONS*

2. SET UP SIDEWALK BOARD **STRUCTURE**

